



Self-Adhering, High Temp Underlayment Installation Instructions

SECURE START[®] HT

Directions for Applying Malarkey Secure Start® HT Self-Adhering, High Temperature Underlayment

GENERAL INSTRUCTIONS

Install Malarkey's 406 Secure Start® HT self-adhering, high temperature underlayment according to adopted building code and local amendments. To qualify for warranty protection and obtain stated coverage, the installation instructions detailed here must be followed. Contact Malarkey Technical Services or check our website at WWW.MALARKEYROOFING.COM for the most current version.

For current warranty information, visit WWW.MALARKEYROOFING.COM/WARRANTY-CENTER.

We assume no responsibility for damage to the underlayment or water damage to the roof deck prior to installation of the finished roofing system, or for leaks due to improper application or failure to properly prepare the surface.

IMPORTANT

- ALWAYS wear fall protection when working on a roof.
- Underlayments can be slippery, particularly when wet or covered with frost or debris. Be careful when walking on them.
- The release film protecting the adhesive of self-adhering membranes is also slippery. Once removed, dispose of it off the roof.
- Roofing materials loaded on the surface of Secure Start® HT should be blocked to prevent slippage.

PRODUCT DESCRIPTION

Product Use: Secure Start® HT is a lightweight, extremely versatile, synthetic membrane suitable for use as a waterproof underlayment in steep slope applications with metal roofing, asphalt shingles, wood shakes/shingles, and mechanically-fastened roof tile.

With its high-temp tolerance, Secure Start® HT is primarily intended for complete deck coverage under metal but also recommended for high elevations, climates causing ice dams, and areas with high winds or wind-driven rain. Secure Start® HT is engineered to perform in temperatures from 40°F (4.4°C) to 260°F (127°C).

Being self-adhering, Secure Start® HT serves a dual role as a flashing membrane, protecting areas susceptible to leaks such as valleys, around roof penetrations (vents, skylights, etc.), and at all roof deck-to-vertical transitions (sidewalls, chimneys, curbs, etc.). We recommend installing Secure Start® HT in these places first, then follow with field application.

Composition and Materials: Secure Start® HT's multi-layer design, plus adhesive, is manufactured for strength and durability. It has a synthetic, textured polypropylene surface while the underside and *selvage edge* are coated with an aggressive, asphalt-based adhesive. The adhesive is protected by split-release film that is removed prior to application.

Storage: Secure Start® HT requires dry, well-ventilated storage and protection from the weather. Storage temps between 40°F (4.4°C) and 100°F (38°C) are recommended for best installation.

Deck Preparation: Roof decks should be sound, smooth, meet adopted building code requirements, and be dry at the time of installation. The presence of moisture can affect the adhesion of the membrane. Sweep dirt and debris from the roof deck.

Minimum approved slope is 2" (51 mm) per 12" (305 mm). Apply underlayment courses parallel to the eaves.

Precautions: Optimum weather conditions are 40°F (4.4°C) and rising throughout the installation process. Note:

- Colder temps can affect adhesion properties so *priming the roof deck may be necessary*. Clean and dry wood decks usually do not require priming, but it is recommended for concrete and masonry surfaces. Use asphalt primer conforming to ASTM D41, and follow the manufacturer's instructions for application.
- Conversely, the warmer the weather, the more aggressive the adhesive becomes. Elevated temperatures can also make it difficult to remove the release film. Moderate temperatures produce the best conditions.

Secure Start® HT is considered a *Class I impermeable vapor retarder*. To prevent harmful condensation beneath the roof sheathing when installing for complete deck coverage, roof structures must be provided with adequate ventilation. Ventilation provisions must meet or exceed current FHA or HUD requirements and adopted building code.

Secure Start® HT is not intended as a permanently-exposed roofing surface but can be left uncovered for up to 180 days if necessary before the primary roof covering is installed. However, good roofing practice dictates the finished roofing material be installed over underlayment as quickly as possible to minimize the chance of blow-off and/or leaks.

Cut the material with straight edge or hook blades; do not use scissors.

In most instances, application of self-adhering membranes is more easily accomplished with two installers.

APPLYING SELF-ADHERING MEMBRANES

Roll out the material, and cut Secure Start® HT into manageable, job-appropriate lengths. Secure Start® HT must be installed completely flat with no wrinkles or buckles.

Begin at a lower corner of roof, and position a length of Secure Start® HT parallel to the eave (atop the drip edge flashing/eave metal), adhesive side down, aligning in the desired position.

Fold the upper half of the membrane back on itself lengthwise to expose the release film on that side: 1) Peel off the release film completely; and 2) Carefully lay that portion back down into place on the roof deck, and apply heavy hand pressure to establish contact.

Once secure, repeat the process for the lower half: fold it back over the adhered upper half, peel off the release film, and return that portion into place. **(See Figure 1)**




Figure 1 - Applying Self-Adhering Membranes

When installing subsequent courses, remove the release film from the selvage edge of the underlying course just before overlapping it. This will keep the adhesive area protected and clean.

As Secure Start® HT membranes are installed, use a hand roller to seal side and end laps, walls, base flashings, etc., and a weighted roller over the entire surface to promote complete adhesion.

In every application of Secure Start® HT, side laps should be 3" (76 mm; the width of selvage edge), vertical end laps in the same course, 6" (152 mm), and staggered 6' (1.8 m) apart in subsequent courses.

Extend Secure Start® HT 6" (152 mm) over hips, ridges and valleys. At roof deck-to-vertical transitions, lap the membrane a minimum of 3" (76 mm) up the transition and secure.

Once the top of an expanse of roof is reached, apply drip edge flashing to the rakes, over the ends of underlayment courses.

If installing in extreme temperatures, below 40°F (4.4°C) or above 100°F (38°C) and on roof slopes 4:12 (102 mm per 305 mm) and greater, Malarkey recommends back-nailing side laps prior to overlapping them. Use metal cap roofing nails with a nominal cap diameter of 1" (25 mm). Fasten in a staggered row, 6" (152 mm) O.C.

T-Joints at End Laps: The construction and treatment of vertical end laps is very important to prevent moisture intrusion.

As mentioned above, the ends of membranes in the same course should overlap 6" (152 mm). At opposing diagonal corners of both underlying and overlapping membranes, make angled, 45° cuts equal to the width of side laps (3" [76 mm]). The underlying piece will have a cut in its down-side corner while the overlapping piece will have a cut in the high-side corner. Properly trimmed corners should be completely covered by application of succeeding courses.

With a ¼" (6 mm) notched trowel, apply a thin, uniform coat (⅛" [3 mm] thick) of trowel-grade adhesive to the entire 6" (152 mm) end lap of the underlying section (including the notched corner), and press the overlapping end down over it. Follow with a roller to promote complete adhesion.

(See Figure 2)




Figure 2 - Construction and Sealing of End Laps

Recommended adhesives:

- Shingle or tile roofs: Asphalt cement conforming to ASTM D4586
- Metal Roofing: A 100% solids, asphalt-compatible sealant such as MasterSeal® NP 1™ or Chem Link® M-1

INSTALLATION FOR COMPLETE DECK COVERAGE

Install the initial, full-width course at the lowest point of the roof deck, flush to the rake and along the eave.

Continue working up the roof, subsequent courses overlapping at side laps 3" (76 mm). Consider back-nailing side laps if conditions merit, especially if the finished roof covering won't be installed for 14 days. (See Figure 3)




Figure 3 - Application of Secure Start® HT for Complete Deck Coverage

INSTALLATION WITH OTHER MALARKEY UNDERLAYMENTS

When complete deck coverage with Secure Start® HT is not required due to weather or finish roofing choice, it may be combined with other Malarkey underlayments once Secure Start® HT is first applied along the eaves.

Roof decks are vulnerable to leaks at the eaves but especially in geographic regions that regularly experience ice dams. For this reason (or if required by building code), install Secure Start® HT up the roof from the eaves, no less than 24" (610 mm) past the interior, warm inside wall of the house or above the expected level of ice dams.

Once past 24" (610 mm), switch to applications of Malarkey's water-resistant, mechanically-attached *field* underlayments (Right Start™ UDL or our line of Secure Start® synthetic underlayments¹), the first course lapped 6" (152 mm) over the termination of self-adhering underlayment. **(See Figure 4)**




Figure 4 - Application of Secure Start® HT and Field Underlayments on Roof Slopes 4:12 and Greater (Ice Dam Regions)

FINAL NOTE

These instructions are meant to act as a general guide. If you have questions about this installation or any Malarkey roofing product, please contact our Technical Services Department weekdays at (800) 545-1191 or (503) 283-1191, 7:00 am to 5:00 pm Pacific Time. You can also email us at:

technicalinquiries@malarkeyroofing.com

Thank you.



P.O. Box 17217
Portland, OR 97217-0217

Rev. 06/20

¹ Installation instructions at WWW.MALARKEYROOFING.com.